



Gang Box Mounting Options



Maximum Recommended Wall Cutout Dimensions



Contacting CyberData

Corporate Headquarters

CyberData Corporation
3 Justin Court
Monterey, CA 93940, USA

Phone: 831-373-2601
Fax: 831-373-4193
www.CyberData.net

Sales: (831) 373-2601 ext. 334
Support: 831-373-2601 ext. 333
Web: <http://www.cyberdata.net/support/contactsupportvoip.html>
RMA Dept: (831) 373-2601 ext. 136
Email: RMA@CyberData.net
RMA Status: <http://www.cyberdata.net/support/rmastatus.html>

Warranty and RMA information is available at the following website:
<http://www.cyberdata.net/support/warranty/index.html>


CyberData
The IP Endpoint Company

Installation Quick Reference

SIP Call Button

SiP Compliant


011049



Parameter	Factory Default Setting
IP Addressing	DHCP
IP Address ^a	10.10.10.10
Web Access Username	admin
Web Access Password	admin
Subnet Mask ^a	255.0.0.0
Default Gateway ^a	10.0.0.1

a. Default if there is not a DHCP server present.

Typical System Installation



Getting Started

- Download the *SIP Call Button Operations Guide* PDF file, from the SIP Call Button product page at: <http://www.cyberdata.net/products/voip/digitalanalog/callbutton/docs.html>
- Create a plan for the locations of your SIP Call Buttons.
- Prior to installation, consult local building and electrical code requirements.
- **WARNING:** This enclosure is not rated for any AC voltages!

SIP Call Button Parts

(1) SIP Call Button Assembly

(1) Wall Mounting Kit


(4) #6 x 1.5 inches Sheet Metal Screw

(4) #6 Ribbed Plastic Anchor


(1) Gang Box Mounting Kit

(4) #6-32 x .375-inch Flat-Head Machine Screw

Dimensions



Terminal Block Connections



Assembly

