

Beronet LineInterface BF2S02FXS (2 BRI / 2 FXS)



Product Name: Beronet LineInterface BF2S02FXS (2 BRI / 2 FXS)

Manufacturer: beroNet

Model Number: BF2S02FXS

Beronet LineInterface BF2S02FXS (2 BRI / 2 FXS)

The bf2S02FXS hybrid module is a 2 Port BRI and 2 Port FXS module for the Mainboards and Boxes. Each BRI port of the bf2S02FXS can be configured as NT (Network Termination) or TE (Terminal Equipment). In both modes, each BRI port can operate in Point-to-multi-point (PMP) or in Point-to Point (PTP) mode. The switching of the TE / NT mode and the switch off the termination resistors can easily be set in the software (Jumper Free) which makes the troublesome reposition jumpers unnecessary. Additionally to the above mentioned 2 BRI Ports the bf2S02FXS provides 2 Port FXS (Foreign Exchange Station) for the solution. FXS interfaces are used to connect devices like analogue phones or faxmachines to your solution.

Comparison Table

Media Function

400 Max. Channels

1600 Max. Channels

6400 Max. Channels

G.711 incl. HW EC

16

64

128

G.726 incl. HW EC

4

16

64

G.729 incl. HW EC

4

16

Beronet LineInterface BF2S02FXS (2 BRI / 2 FXS)

64

G.723 incl. HW EC

4

16

64

T.38

4

16

32

Specification

• 2 BRI Ports

• each port can be configured individually for TE / NT mode

• line termination switchable (100 ohms)

• TE/NT mode and line termination is selectable via software (Jumperfree)

• all BRI ports are short-circuit protected (by electronic fuse, auto-reset)

• 2 FXS Ports

• FXS Loop Start

• FXS Kewl Start

• Hardware bridging (for transparent voice, data and fax transmission)

Accessories

• BFBridge (to use all 4 RJ45 slots on a mainboard with one bf4S0,bf4FXS,bf4FXO,bf2S02FXS)

• BFTAdapters (to connect 2 BRI or analogue Lines on one RJ45 of the solution)

• BFPCM (PCM Cable to interconnect mainboards and boxes)

• BFE1Cross, (2m shielded, E1/T1 "cross-over" cable)

• BF19bracket (19 inch rack mount bracket for Boxes)

• BFANTL (small 7 cm stock antenna for BF2GSM modules)

• BFANTL (2m cable antenna with magnetic foot for BF2GSM modules)

• BFFXXCable (RJ45 to RJ11 cable to use with analogue modules)

Beronet LineInterface BF2S02FXS (2 BRI / 2 FXS)

Please Enquire
