

## Beronet LineInterface BF2S02FXS (2 BRI / 2 FXS)



Product Name: Beronet LineInterface BF2S02FXS (2 BRI / 2 FXS)

Manufacturer: beroNet

Model Number: BF2S02FXS

Beronet LineInterface BF2S02FXS (2 BRI / 2 FXS)

The bf2S02FXS hybrid module is a 2 Port BRI and 2 Port FXS module for the Mainboards and Boxes. Each BRI port of the bf2S02FXS can be configured as NT (Network Termination) or TE (Terminal Equipment). In both modes, each BRI port can operate in Point-to-multi-point (PMP) or in Point-to Point (PTP) mode. The switching of the TE / NT mode and the switch off the termination resistors can easily be set in the software (Jumper Free) which makes the troublesome reposition jumpers unnecessary. Additionally to the above mentioned 2 BRI Ports the bf2S02FXS provides 2 Port FXS (Foreign Exchange Station) for the solution. FXS interfaces are used to connect devices like analogue phones or faxmachines to your solution. Comparison Table

Media Function
400 Max. Channels
1600 Max. Channels
6400 Max. Channels
G.711 incl. HW EC
16
64
128
G.726 incl. HW EC
4

G.729 incl. HW EC

4

64

16



## Beronet LineInterface BF2S02FXS (2 BRI / 2 FXS)

64
G.723 incl. HW EC
16
64
T.38
4
16
32
Specification
Titly 2 BRI Ports Titly each port can be configured individually for TE / NT mode Titly line termination switchable (100 ohms) Titly TE/NT mode and line termination is selectable via software (Jumperfree) Titly all BRI ports are short-circuit protected (by electronic fuse, auto-reset) Titly 2 FXS Ports Titly FXS Loop Start Titly FXS Kewl Start Titly Hardware bridging (for transparent voice, data and fax transmission)
Accessories
Ti¿½ BFBridge (to use all 4 RJ45 slots on a mainboard with one bf4S0,bf4FXS,bf4FXO,bf2S02FXS) Tiξ½ BFTAdapters (to connect 2 BRI or analogue Lines on one RJ45 of the solution) Tiξ½ BFPCM (PCM Cable to interconnect mainboards and boxes) Tiξ½ BFE1Cross, (2m shielded, E1/T1 "cross-over" cable) Tiξ½ BF19bracket (19 inch rack mount bracket for Boxes) Tiξ½ BFANTS (small 7 cm stock antenna for BF2GSM modules) Tiξ½ BFANTL (2m cable antenna with magnetic foot for BF2GSM modules) Tiξ½ BFFXXCable (RJ45 to RJ11 cable to use with analogue modules)



## Beronet LineInterface BF2S02FXS (2 BRI / 2 FXS)

Please Enquire